

Comfort-Aire®

Century®



WIRED CONTROLLER
Installation and Owner's Manual
Hyper Heat
Single-Zone

Control Model
KJR-120X/TFBG-E

Models

VCD18, 24, 30, 36, 48, 60 SA Series

IMPORTANT NOTE:

Please read this manual carefully before installing or operating your wired remote controller. Make sure to save this manual for future reference.

This manual gives detailed description of the precautions that should be brought to your attention during operation.

In order to ensure correct service of the wired controller please read this manual carefully before using the unit.

For convenience of future reference, keep this manual after reading it.

All the pictures in this manual are for explanation purposes only. There may be slight differences from the wired remote controller you purchased (depending on model). The actual shape shall prevail.




Table of Contents

1. Safety precaution	1
2. Installation accessories	2
3. Installation method	4
4. Specifications.....	12
5. Feature and function of the wired controller	13
6. Names on the LCD of the wired controller	14
7. Names of buttons on the wired controller	15
8. Preparatory operation	16
9. Operation	17
10 Timer functions	26
11. Weekly Timer 1	29
12.Weekly Timer 2	35
13.Fault alarm handling	42
14.Technical indication and requirements	42
15.Queries and settings	43

1. Safety precaution



WARNING

- Please entrust the distributor or professionals to install the unit.
- Installation by other persons may lead to imperfect installation, electric shock or fire.
- Adhere to this installation manual.
- Reinstallation must be performed by professionals.

NOTE

- Do not install the unit in a place vulnerable to leakage of flammable gases. Once flammable gases are leaked and left around the wire controller, fire may occur.
- Do not operate with wet hands or let water enter the wire controller. Otherwise, electric shock may occur.

1. Safety precaution

NOTE

- The specified cables shall be applied in the wiring. No external force may be applied to the terminal. Otherwise, broken wires and heating may occur and result in fire.

2. Installation accessory

Select the installation location

Preparation before installation

1. Please confirm that all the following parts have been supplied.

No.	Name	Qty.	Remarks
1	Wire controller	1	_____
2	Installation and owner's manual	1	_____
3	Screws	3	M3.9X25 (For Mounting on the Wall)
4	Wall plugs	3	For Mounting on the Wall
5	Screws	2	M4X25 (For Mounting on switch box)
6	Plastic screw bars	2	For fixing on switch box
7	Battery	1	
8	The connective wires group	1	Optional
9	Screw	1	M4X8(For Mounting the connective wire group)

2. Installation accessory

2. Prepare the following assemblies on the site.

No.	Name	Qty.(embedded into wall)	Specification (only for reference)	Remarks
1	Switch box	1	_____	_____
2	Wiring Tube(Insulating Sleeve and Tightening Screw)	1	_____	_____

Precaution of installing the wired controller

1. This manual provides the installation method of the wired controller. Please refer to the wiring diagram of this installation manual to connect the wired controller with indoor unit.
2. The wired controller works in a low voltage loop circuit. DO NOT directly contact the cable to high voltage above, 24V. Wiring clearance between configured tubes should be at the range of 300~500mm or above.
3. The Shielded wire of the wired controller must be grounded.

3. Installation method

1. Wired remote controller structural dimensions




Fig 3-1

2. Remove the upper part of wired controller

- Insert a slot screwdriver into the slots in the lower part of the wired controller (2 places), and remove the upper part of the wired controller. (Fig.3-2)




Fig 3-2

3. Installation method

NOTE: The PCB is mounted in the upper part of the wired controller. Be careful not to damage the board with the slot screwdriver.

3. Fasten the back plate of the wired controller

- For exposed mounting, fasten the back plate on the wall with the 3 screws (M4×20) and plugs. (Fig.3-3)




Fig 3-3

- Use two M4X25 screws to install the back cover on the 86 switch box, and use one M3.9X25 screw to fix to the wall.




Fig 3-4

3. Installation method

NOTE: Put on a flat surface. Be careful not to distort the back plate of the wire controller by overtightening the mounting screws.

4. Battery installation




Fig 3-5

- Put the battery into the installation site and make sure the positive side of the battery is in accordance with the positive side of installation site.(See Fig.3-5)
- Please set the time correctly the first time batteries are installed. Batteries in the wired controller can keep time under power failure which ensures the time is right. When the power restores, if the time displayed is not correct, it means the battery is dead and you need to replace the battery.

3. Installation method

5. Wire with the indoor unit




Fig 3-6

1 Indoor unit

2 Notch the part for the wiring to pass through with nippers, etc. Connect the terminals on the remote controller (HA ,HB), and the terminals of the indoor unit (HA ,HB). (HA and HB do not have polarity.)

NOTE:

- DO NOT allow water to enter the wired controller. Use the trap and putty to seal the wires.
- Connecting wires must be fixed reliably and cannot be pulled.

3. Installation method

For some units, the wired controller connects to the unit HA and HB ports through the HA and HB ports. There is no polarity between HA and HB. See Fig. 3-7




Fig.3-7

3. Installation method

The main/secondary wired controller can be used to enable two wired controllers to control one unit, and the wired controllers connect to the unit HA and HB ports through the HA and HB port on the controller. There is no polarity between HA and HB. See Fig. 3-8




Fig.3-8

3. Installation method

For some units, one wired controller can support multiple units (a maximum of 16 units). In this case, the wired controller and unit need to be connected to the HA and HB ports at the same time. In group control, there will be no error displayed on the wired controller. See Fig. 3-9




Fig.3-9

3. Installation method




Fig 3-10

6. Reattach the upper part of the wired controller

- After adjusting the upper case, buckle the upper case; avoid clamping the wiring during installation. (Fig 3-11)




Fig 3-11

All the pictures in this manual are for explanation purposes only. Your wired controller may be slightly different. The actual shape shall prevail.

4. Specification

Input voltage	DC 12V
Ambient temperature	23~110°F
Ambient humidity	RH40%~RH90%

Wiring specifications

Wiring type	Size	Total length
shielded vinyl cord or cable	18g	66'
	14g	164'

5. Feature and function of the wired controller




Feature:

- LCD display.
- Malfunction code display: it can display the error code, helpful for service.
- 4-way wire layout design, no raised part on the back, more convenient to place the wires and install the device.
- Room temperature display. Weekly
- Timer.

Function:


- Mode: choose Auto-Cool-Dry-Heat - Fan
- Fan speed: Auto/Low/Med/High speed
- Swing(on some models)
- Timer ON/OFF
- Temp setting
- Weekly timer
- Follow me
- Turbo
- 24-hour System
- 12-hour System
- Sleep
- 8 degree heating function (on some models)
- Auto-restart
- Individual louver control (on some models)
- Automatic airflow test
- Rotation&Back-up
- Dual Control
- Group Control
- Child Lock
- LCD display
- Clock

6. Name on the LCD of the wired controller



- | | |
|--|---|
| 1 Operation mode indication | 9 Follow Me function indication |
| 2 Fan speed indication | 10 Sleep mode indication |
| 3 Temperature display | 11 Electric Auxiliary Heat/
Turbo function indication(some models) |
| 4 Lock indication | NOTE: AHU models only have turbo functions. |
| 5 °C / °F indication | 12 Left-right swing indication
(some models) |
| 6 Rotating indication | 13 Clock display |
| 7 Main unit and secondary
unit indication | 14 On/Off timer |
| 8 Room temperature indication | 15 Timer display |

7. Name of button on the wired controller



- 1 POWER button
- 2 MODE button
- 3 DAY OFF/DEL button
- 4 ADJUST button
- 5 CONFIRM button

- 6 TIMER button
- 7 FAN SPEED button
- 8 BACK button
- 9 SWING button
- 10 FUNC. button
- 11 COPY button

8. Preparatory operation

Set the current day and time

- 1  Press the Timer button for 2 seconds or more. The timer display will flash.

- 2  Press the button “∨” or “∧” to set the date. The selected date will flash.



- 3  The date setting is finished and the time setting is prepared after pressing Timer button or CONFIRM button or there is no button pressed in 10 seconds.

- 4  Press the button “∨” or “∧” to set the current time. Press repeatedly to adjust the current time in 1-minute increments. Press and hold to adjust the current time continuous.



ex. Monday 11:20

- 5  The setting is done after pressing CONFIRM button or there is no button pressed in 10 seconds.

9. Operation

- 6  Time scale selection
 Pressing the buttons “” and “” for 2 seconds will alternate the clock time display between the 12h & 24h scale.

To start/stop operation



Press the Power button.

8 degree heating function (on some models)



When the heating mode is 60°F/62°F , press the down button twice within 1 second to turn on the 8 ° heating function, and press the Power, Mode, adjust , Fan speed, Timer, and Swing button to cancel the 8° heating function.

NOTE:

For some models, the 8° heating function can only be set by remote control, you can not choose this function by wired controller.


9. Operation

To set the operation mode

Operation mode setting



Press the Mode button to set the operation mode. (Heat function is invalid for cool only type unit)




For AHU models:



- When the mode is selected as emergency heating (single-on electric auxiliary heating) mode,  is displayed in the mode area, the fan speed displays automatic wind, and the fan speed key does not respond.
- There is no sleep, 8-degree heating, turbo functions in emergency heating mode.
- When the mode is selected as heating + electric auxiliary heating mode,  is displayed in the mode area, and there is no turbo function.

9. Operation

Room temperature setting



Press the button “ \vee ” or “ \wedge ” to set the room temperature.

Indoor Setting Temperature Range :
60~86°F / 62~86°F or according to the set temperature range of the unit.

°C & °F scale selection (on some models)

Pressing the buttons “ \vee ” and “ \wedge ” for 3 seconds will alternate the temperature display between the °C & °F scale.

Fan speed setting



Press the Fan speed button to set the fan speed. (This button is unavailable when in the mode of Auto or Dry)



Keypad tone setting



Press the buttons Swing and FUNC. for 3 seconds to close the keypad tone.

Press the buttons again for 3 seconds to open the keypad tone.

9. Operation

Child lock function



Press the buttons “  ” and “  ” for 2 seconds to activate the child lock function and lock all buttons on the wire controller.

Press the buttons again for 2 seconds to deactivate the child lock function.

When the child lock function is activated, the  mark appears.

Swing function (For the unit left & right auto swing models only)

1 Up-Down swing



Press the SWING button to start up-down swing function. Press it again to stop.

When the Up-Down swing function is activated, the  mark appears.

2 Left-Right swing

Press the Swing button long to start Left-Right swing function. Press it again to stop. When the Left-Right swing function is activated, the  mark appears.

9. Operation

Swing function (For the unit without left & right auto swing function models)

Up-Down airflow direction and swing



- Use Swing button to adjust the Up-down airflow direction.

1. Press the button, each time the louver swings 6 degrees.
2. Press and hold the button for 2 seconds, it turns into up-down swing mode, press it again to stop. When the Up-Down swing function is activated, the  mark appears. (Not applicable to all the models)

The operation can refer to the following instructions for the

- unit with four Up-Down louvers that can be operated individually.



1. Press the Swing button to activate the Up-Down adjusting louver function.

The  mark will flash. (Not applicable to all the models)

2. Pressing the button " " or " " can select the movement of four louvers. Each time you push the button, the wire controller select in a sequence that goes from: (the icon  means the four louvers move at the same time.)

9. Operation




3. And then use Swing button to adjust the Up-Down airflow direction of the selected louver.



Press the FUNC. button to set the turbo or rotating or lfeel function.



The select function icon will flash then press the Confirm button to confirm the setting.



Sleep function



In automatic, cooling or heating mode, press the FUNC. button to select the sleep icon, and then press the OK button to turn on or off the sleep function, and set the wind speed to display as automatic wind.

After the sleep function is turned on, turning on turbo, 8-degree heating, switching modes, or adjusting the wind speed will cancel the sleep function.

9. Operation

Turbo function (on some models)



Under COOL/HEAT mode ,press the FUNC. button to activate the turbo function. Press the button again to deactivate the turbo function.

When the turbo function is activated,the  mark appears. In heating mode, if there is a PTC, turn on the PTC function.


NOTE: The electric auxiliary heating function of the AHU model is switched by the MODE button , and the FUNC. button is a turbo function.

Follow me function indication

Press the FUNC. button to select whether the room temperature is detected at the indoor unit or the wire controller.

When the follow me function indication appears,the room temperature is detected at the wire controller. 

Press the button again to cancel the follow me function.



9. Operation

Rotation & Back-up indication

When there are two units, press the button to select the rotating function, and press "Confirm" to turn on or off the rotating function.

1. Press "Confirm" to set the rotating time, then press the button " \surd " or " \wedge " to set time. Setting time Range : 1~99h, the default time is 10 hours.
2. Step 2 set high temperature co-open temperature -- or 79-89 degrees -- that is, this function is invalid. When the ambient temperature is 79-89 degrees, when the ambient temperature is greater than or equal to the set temperature, the two machines will run 75 degrees at the same time in the COOL mode.
3. Step 3 set the low-temperature co-open temperature -- or 41-59 degrees -- that is, this function is invalid. When the ambient temperature is 41-59 degrees, when the ambient temperature is lower than the set temperature, the two machines will run at the same time for 75 degrees to make the heating mode.

9. Operation


4. Step 4: set which machine will run first. Select A or B.
5. After this function is turned on, as long as the air conditioner is running at the setting hour, it will automatically turn on another air conditioner and turn off the current air conditioner. Press the POWER button to switch to another one immediately. A or B icons flicker to indicate the corresponding air conditioning failure.
Automatically switch to another machine when running time is reached or machine failure occurs.

10. Timer functions

- WEEK** WEEKLY timer
Use this timer function to set operating times for each day of the week.
- ON** **DAY** On timer
Use this timer function to start air conditioner operation. The timer operates and air conditioner operation starts after the time has passed.
- OFF** **DAY** Off timer
Use this timer function to stop air conditioner operation. The timer operates and air conditioner operation stops after the time has passed.
- ON**
OFF **DAY** On and Off timer
Use this timer function to start and stop air conditioner operation. The timer operates and air conditioner operation starts and stops after the time has passed.

10. Timer functions

To set the On or Off TIMER

- 1  Press the Timer button to select the **ON DAY** or **OFF DAY**.
- 
- ```

 graph LR
 A[WEEK 1] --> B[WEEK 2]
 B --> C[ON DAY]
 C --> D[OFF DAY]
 D --> E[ON/OFF DAY]
 E --> F[No display]

```

- 2  Press the Confirm button and the Timer display is flashing.




- 3   
- ex. Off timer set at 18:00

Press the button “∨” or “∧” to set the time.  
After the time is set, the timer will start or stop automatically.

- 4  Press the Confirm button again to finish the settings.

## 10. Timer functions

To set the On and Off TIMER

-  Press the Timer button to select the  .
-  Press the Confirm button and the Clock display is flashing.
-   
 Press the button “” or “” to set the time of On timer, and then press the Confirm button to confirm the setting.
-  Press the button “” or “” to set the time of Off timer.
-  Press the Confirm button to finish the settings.

**NOTE:** The secondary wired controller cannot set the timer.

## 11. Weekly Timer 1

### 1 Weekly timer setting



Press the Timer button to select the **WEEK** and then press the Confirm button to confirm.



### 2 Day of the week setting



Press the button “ $\vee$ ” or “ $\wedge$ ” to select the day of the week and then press the Confirm button to confirm the setting.



### 3 ON timer setting of timer setting 1



Press the button “ $\vee$ ” or “ $\wedge$ ” to set the time of On timer and then press the Confirm button to confirm the setting.



## 11. Weekly Timer 1



ex. Tuesday time scale 1

Up to 4 timer settings can be saved for each day of the week. It is convenient if the WEEKLY TIMER is set according to the user's life style.

### 4 Off timer setting of timer setting 1



Press the button "✓" or "←" to set the time of Off timer and then press the Confirm button to confirm the setting.



ex. Tuesday time scale 1

5 Different timer settings can be set by repeating step 3 to 4.

6 Other days in one week can be set by repeating step 2 to 5.


**NOTE:** The weekly timer setting can be returned to the previous step by pressing Back button. The time of timer setting can be deleted by pressing Day off button. The current setting will be restored and stop the weekly timer setting automatically when there is no operation for 30 seconds.

## 11. Weekly Timer 1

### WEEKLY timer operation

To activate WEEKLY TIMER operation

Press the Timer button while **WEEK** is displayed on the LCD.




To deactivate WEEKLY TIMER operation

Press the Timer button while **WEEK** is disappear from the LCD.



To turn off the air conditioner during the weekly timer

1. If you press the Power button once and quickly, the air conditioner will turn off temporarily. And the air conditioner will turn on automatically until the time of On timer.



ex. If press the POWER button once and quickly at 10:00, The air conditioner will turn on at 14:00.

2. When press the Power button for 2 seconds, the air conditioner will turn off completely, at the same time canceling the timing function.

## 11. Weekly Timer 1

To set the DAY OFF (for a holiday)


- 1  During the weekly timer, press the Confirm button.

---

- 2  Press the button “∨” or “∧” to select the day in this week.

---

- 3  Press the Day off button to set the DAY OFF.
 



ex.The DAY OFF is set for Wednesday

---

- 4 The DAY OFF can be set for other days by repeating the steps 2 and 3.

---

- 5  Press the Back button to go back to the weekly timer.

To cancel: Follow the same procedures as those for setup.

Notes:



The DAY OFF setting is cancelled automatically after the set day has passed.

## 11. Weekly Timer 1

### DELAY function



During the weekly timer, pressing the Del button once, display "0h". Press this button twice, display "1h" and wait 3 seconds to confirm. It means the unit will override 1 hours; Press this button three times, display "2h" and wait 3 seconds to confirm. It means the unit will override 2 hours;



ex. If press the DEL button to select "2h" at 18:05 ,  
The air conditioner will delay to turn off at 20:05.

Copy out the setting in one day into the other day.

A reservation made once can be copied to another day of the week. The whole reservation of the selected day of the week will be copied. The effective use of the copy mode ensures ease of making reservations.



During the weekly timer, press the Confirm button.



Press the button "∨" or "∧" to select the day to copy from.


## 11. Weekly Timer 1

- 3  Press the Copy button, the letter "CY" will be shown on the LCD.

- 4  Press the button "∨" or "∧" to select the day to copy to.

- 5  Press the Copy button to confirm .

The  mark flashes quickly



ex. Copy the setting of Monday to Wednesday

- 6 Other days can be copied by repeating step 4 and 5.

- 7  Press the Confirm button to confirm the settings.

- 8  Press the Back button to go back to the weekly timer.

## 12. Weekly Timer 2

### 1 Weekly timer setting



Press Timer to select the **WEEK** and press Confirm.

### 2 Day of the week setting



Press “ $\vee$ ” or “ $\wedge$ ” to select the day of the week and then press CONFIRM.



### 3 ON timer setting of timer setting 1




Press “ $\vee$ ” or “ $\wedge$ ” to select the setting time. The setting time, mode, temperature and fan speed appear on the LCD. Press CONFIRM to enter the setting time process.



## 12. Weekly Timer 2

**IMPORTANT:** Up to 8 scheduled events can be set on one day. Various events can be scheduled in either MODE, TEMPERATURE and FAN speeds.




ex. Tuesday time scale 1

### 4 Time setting




Press “ $\nabla$ ” or “ $\triangle$ ” to set the time then press CONFIRM.

### 5 Operation mode setting



Press “ $\nabla$ ” or “ $\triangle$ ” to set the operation mode then press CONFIRM.



**NOTE:** The specific mode changes according to the mode of the actual model.

### 6 Room temperature setting



Press “ $\nabla$ ” or “ $\triangle$ ” to set the room temperature then press CONFIRM.

**NOTE:** This setting is unavailable in the FAN or OFF modes.

## 12. Weekly Timer 2


### 7 Fan speed setting



Press “ $\vee$ ” or “ $\wedge$ ” to set the fan speed then press CONFIRM.



NOTE: This setting is unavailable in the AUTO, DRY or OFF modes.



**8 Different scheduled events can be set by repeating steps 3 through 7.**

**9 Additional days, in a one week period, can be set by repeating steps 3 through 8.**

NOTE: The weekly timer setting can be returned to the previous step by pressing BACK. The current setting is restored. The controller will not save the weekly timer settings if there is no operation within 30 seconds.

## 12. Weekly Timer 2

### WEEKLY timer operation

To start

Press Timer to select the **WEEK** , and then the timer starts automatically.



ex.

To cancel

Press the Power button for 2 seconds to cancel the timer mode.



The timer mode can also be canceled by changing the timer mode using Timer.



To set the DAY OFF (for a holiday)

1



After setting the weekly timer, press CONFIRM.

2



Press “” or “” to select the day of the week.

## 12. Weekly Timer 2




Press DAY OFF to create an off day.



ex. The DAY OFF is set for Wednesday

4 Set the DAY OFF for other days by repeating the steps 2 and 3.



To cancel, follow the same procedures used for setup.

**NOTE:** The DAY OFF setting is cancelled automatically after the set day has passed.

Copy out the setting in one day into the other day.

A scheduled event, made once, can be copied to another day of the week. The scheduled events of the selected day of the week will be copied. The effective use of the copy mode ensures the ease of reservation making.



## 12. Weekly Timer 2


2  Press “∨” or “∧” to select the day to copy from.

3  Press COPY, the letters CY appear on the LCD.

4  Press “∨” or “∧” to select the day to copy to.

5 Press COPY to confirm.

The **WE** mark flashes quickly



ex. Copy the setting of Monday to Wednesday

6 Other days can be copied by repeating steps 4 and 5.

7  Press CONFIRM to confirm the settings.

8  Press BACK to revert to the weekly timer.

## 12. Weekly Timer 2


Delete the time scale in one day.

1  During the weekly timer setting, press CONFIRM.

2   Press “∨” or “∧” to select the day of the week and then press CONFIRM.

3   Press “∨” or “∧” to select the setting time you want to delete. The setting time, mode, temperature and fan speed appear on the LCD. The setting time, mode, temperature and fan speed can be deleted by pressing the DEL (day off).

Press “∨” or “∧” to select the setting time you want to delete. The setting time, mode, temperature and fan speed appear on the LCD. The setting time, mode, temperature and fan speed can be deleted by pressing the DEL (day off).



ex. Delet the time scale 1 in saturday

### 13. Fault alarm handling

If the system does not properly operate except the above mentioned cases or the above mentioned malfunctions is evident, investigate the system according to the following procedures.

| NO. | MALFUNCTION & PROTECTION DEFINE                                | DISPLAY DIGITAL TUBE |
|-----|----------------------------------------------------------------|----------------------|
| 1   | Error of communication between wire controller and indoor unit | EH63                 |

The errors displayed on the wired controller are different from those on the unit. If error code appears, please check the <<Owner's And Installation Manual>>and<<SERVICE Manual>>.


### 14. Technical indication and requirement

EMC and EMI comply with the CE certification requirements.

## 15. Queries and settings



When the air conditioning unit has switched machines, press "COPY" for 3 seconds, first displays P:00, if connected to an indoor unit, displays P:00, if connected to multiple indoor units, press "∨" or "∧" to display P:01, P:02, and then press "Confirm" to enter the query for the indoor unit. Tn(T1~T4) temperature and fan fault(CF), press "∨" or "∧" to select.



Not operating any keys for 15 seconds or pressing "Back" or pressing "ON/OFF" drops you out of query temperature.



When the air conditioning unit is off, to get into the query function of temperature, press "∨" or "∧" to select SP, press "Confirm" to adjust the static pressure value.



When the air conditioning unit is off, to get into the query function of temperature, press "∨" or "∧" to select AF, press "Confirm" into test mode, press "Back" or press "ON/OFF" or press "Confirm" drop out of test mode. In AF mode, 3~6 minutes test completion automatically exits, if the test process, press "Back" or press "ON/OFF" or press "Confirm", the test exits will be interrupted.

## 15. Queries and settings

### Follow me function temperature compensation



When the air conditioning unit is off, to get to into the query function of temperature, press “∨” or “∧” to select tF.




The compensation temperature Range : 23 - 41°F. Press “Confirm” into setting state, press “∨” or “∧” to select the temperature, then press “Confirm” to complete it.

tF

tF : compensation temperature



When the air conditioning unit is off, to get into the query function of temperature, press “∨” or “∧” to select type. Press “Confirm” into setting state, press “∨” or “∧” to select the type, then press “Confirm” to complete it.



TYPE

CH:   
AUTO COOL DRY HEAT FAN

HH:   
HEAT FAN

CC:   
COOL DRY FAN

NA:   
COOL DRY HEAT FAN

## 15. Queries and settings

### Set the highest and lowest temperature values



When the air conditioning unit is off, to get into the query function of temperature, press “ $\vee$ ” or “ $\wedge$ ” to select tHi or tLo. Press “Confirm” into setting state, press “ $\vee$ ” or “ $\wedge$ ” to select the temperature, then press “Confirm” to complete it.

The highest setting temperature range : 77-86°F The lowest setting temperature range: 63-75°F.

$tHi$  : Highest value setting function.

$tLo$  : Minimum value setting function.

### Remote control function selection of wire controller



When the air conditioning unit is off, to get into the query function of temperature, press “ $\vee$ ” or “ $\wedge$ ” to select rEC. ON or OF will be displayed in the temperature area to indicate whether it is valid or invalid.

When the selection is invalid, the wired controller does not process any remote control signals. Press “Confirm” into setting state, press “ $\vee$ ” or “ $\wedge$ ” to select , then press “Confirm” to complete it.

## 15. Queries and settings

### Two - line controller address selection



Adr

When the air conditioning unit is off, to get into the query function of temperature, press “ $\vee$ ” or “ $\wedge$ ” to select Adr, the temperature zone will display -- or A, B. Where -- refers to the code setting of the wire controller.

Press “Confirm” into setting state, press “ $\vee$ ” or “ $\wedge$ ” to select , then press “Confirm” to complete it.

-- : The code setting  of the wired controller shall prevail.

Adr : The wired controller address setting.

### Restore factory Settings



INIt

When the air conditioning unit is off, to get into the query function of temperature, press “ $\vee$ ” or “ $\wedge$ ” to select INIt, the temperature zone displayed --.

Press “Confirm” into setting state, press “ $\vee$ ” or “ $\wedge$ ” to select to "ON" , then press “Confirm” to complete it.

INIt : Restore factory Settings .

## 15. Queries and settings

After the wired controller resumes the factory parameter setting, the rotating parameter setting is restored to 10 hours (the highest and lowest temperature are not set); The compensation of body temperature is uncompensated; COOL and HEAT/ single COOL mode is restored to COOL and HEAT model; The temperature range was restored to 60~86°F / 62~86°F. Remote receiving function is restored to be effective; The address of the two-control first-line controller is restored to the code switch.

**PAGE INTENTIONALLY LEFT BLANK**

---

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product. Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.

*Comfort-Aire*<sup>®</sup>

**Century**<sup>®</sup>

1900 Wellworth Ave., Jackson, MI 49203 • Ph. 517-787-2100 • [www.marsdelivers.com](http://www.marsdelivers.com)

