





## Enhanced Air Handler

HMA-VX1S

Parts List

# HMA-VX1S Parts List • Air Handler



**HMA-VX1S Parts List • Air Handler**

| Drawing | Description                              | HMA18VX1 | HMA24VX1 | HMA30VX1 | HMA36VX1 | HMA42VX1 | HMA48VX1 | HMA60VX1 |
|---------|--|----------|----------|----------|----------|----------|----------|----------|
| 0       | 106677-01 HARNESS-WIRING AH              | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 0       | FUSE 3 AMP 32 VOLT                       | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 0       | KIT - THUMB SCREW                        | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 0       | KIT - RETAINER WASHER                    | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 0       | KIT - CABINET PLUG                       | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 1       | 104824-01 TRANSFORMER 208/240V PRI, 24V  | 1        | 1        | 1        | 1        |          |          |          |
| 1       | 51M4401 TRANS 208/240VPRI, 24VSEC, 70VA  |          |          |          |          | 1        | 1        | 1        |
| 5       | 40K8201 CTL BDC3-1                       |          |          |          | 1        |          |          |          |
| 24      | 627730-01 RDS AHU STANDARD CONTROL KIT   | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 25      | 627707-01 ASSY - REPAIR PART COIL        | 1        |          |          |          |          |          |          |
| 25      | Assy - Repair Part Coil                  |          | 1        |          |          |          |          |          |
| 25      | Assy - Repair Part Coil                  |          |          | 1        |          |          |          |          |
| 25      | Assy - Repair Part Coi                   |          |          |          | 1        |          |          |          |
| 25      | Assy - Repair Part Coil                  |          |          |          |          | 1        |          |          |
| 25      | Assy - Repair Part Coil                  |          |          |          |          |          | 1        |          |
| 25      | Assy - Repair Part Coil                  |          |          |          |          |          |          | 1        |
| 69      | 627374-01 HARNESS-WIRING #VS             | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 69      | 104755-02 BAND-MOTOR MOUNT (4 LEG)       | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 69      | 104757-01 ARM-MOTOR MTG                  | 3        | 3        | 3        | 3        | 3        |          |          |
| 69      | 104757-02 ARM-MOTOR MTG                  |          |          |          |          |          | 3        | 3        |
| 69      | 106677-02 NIDEC MOTOR POWER HARNESS      | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 69      | 107598-01 MOTOR-BLOWER 1/2 HP VS 16PIN   | 1        | 1        | 1        | 1        |          |          |          |
| 69      | 107598-03 MOTOR-BLOWER 1 HP VS 16PIN     |          |          |          |          | 1        | 1        | 1        |
| 69      | 620605-15 CONTROL CBA25UHV018            | 1        |          |          |          |          |          |          |
| 69      | 620605-16 CONTROL CBA25UHV024            |          | 1        |          |          |          |          |          |
| 69      | 620605-17 CONTROL CBA25UHV030            |          |          | 1        |          |          |          |          |
| 69      | 620605-18 CONTROL CBA25UHV036            |          |          |          | 1        |          |          |          |
| 69      | 620605-19 CONTROL CBA25UHV042            |          |          |          |          | 1        |          |          |
| 69      | 620605-20 CONTROL CBA25UHV048            |          |          |          |          |          | 1        |          |
| 69      | 620605-21 CONTROL CBA25UHV060            |          |          |          |          |          |          | 1        |
| 69      | 620606-01 KIT 4 PIN HARNESS (106401-01)  | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 69      | 627374-01 HARNESS-WIRING #VS             |          |          | 1        |          |          |          |          |
| 74      | BLOWER HOUSING ASSY, 9X10                |          |          |          |          | 1        |          |          |
| 74      | BLOWER HOUSING ASSY 12X10                |          |          |          |          |          | 1        | 1        |
| 74      | BLOWER HOUSING ASSY 9X6R 4 Hole Mount    | 1        | 1        |          |          |          |          |          |
| 74      | BLOWER HOUSING ASSY 10X8R 4 Hole Mount   |          |          | 1        |          |          |          |          |
| 74      | BLOWER HOUSING ASSY 10X8R NEW LH Scroll  |          |          |          | 1        |          |          |          |
| 84      | PANEL PATCH PLATE 618464-02              | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 154     | 104110-07 VALVE-TXV (3.5-5) (R410A)      |          |          |          |          |          | 1        |          |
| 154     | 108030-01 VALVE-TXV (1.5-3 Ton) (R454B)  | 1        | 1        | 1        |          |          |          |          |
| 154     | 108030-02 VALVE-TXV (3.5-4 Ton) (R454B)  |          |          |          | 1        |          |          |          |
| 154     | 108030-03 VALVE-TXV (5 Ton) (R454B)      |          |          |          |          | 1        | 1        | 1        |
| 303     | 627693-01 COIL SENSOR REPAIR KIT         | 1        | 1        | 1        | 1        | 1        | 1        | 1        |
| 309     | 620622-01 ASSY-KIT DRAIN PAN (21 X 16)   | 1        | 1        | 1        |          |          |          |          |
| 309     | 620622-02 ASSY-KIT DRAIN PAN (21 X 19)   |          |          |          | 1        | 1        | 1        | 1        |
| 310     | 620622-03 ASSY-KIT DRAIN PAN 1.5-2.5tn H | 1        | 1        | 1        |          |          |          |          |
| 310     | 620622-04 ASSY-KIT DRAIN PAN HZ (3-4T)   |          |          |          | 1        | 1        | 1        |          |
| 310     | 620622-05 ASSY-KIT DRAIN PAN HZ (5TON)   |          |          |          |          |          |          | 1        |
| 963     | PANEL FILTER ACCESS 18/24/30 618465-05   | 1        | 1        | 1        |          |          |          |          |
| 963     | PANEL FILTER ACCESS 36-60 618465-06      |          |          |          | 1        | 1        | 1        | 1        |
| 990     | PANEL BLOWER ACCESS 18/24 618396-05      | 1        | 1        |          |          |          |          |          |
| 990     | PANEL BLOWER ACCESS 30 618396-06         |          |          | 1        |          |          |          |          |
| 990     | PANEL BLOWER ACCESS 36/42/60 618396-08   |          |          |          | 1        | 1        |          | 1        |
| 990     | PANEL BLOWER ACCESS 48 618396-07         |          |          |          |          |          | 1        |          |
| 995     | PANEL PLUMBING ACCESS 18 618397-07       | 1        |          |          |          |          |          |          |
| 995     | PANEL PLUMBING ACCESS 24 618397-08       |          | 1        |          |          |          |          |          |
| 995     | PANEL PLUMBING ACCESS 30 618397-09       |          |          | 1        |          |          |          |          |
| 995     | PANEL PLUMBING ACCESS 36-42 618397-10    |          |          |          | 1        | 1        |          |          |
| 995     | PANEL PLUMBING ACCESS 48 618397-11       |          |          |          |          |          | 1        |          |
| 995     | PANEL PLUMBING ACCESS 60 618397-12       |          |          |          |          |          |          | 1        |

Due to ongoing product improvements, specifications and dimensions are subject to change and correction without notice or incurring obligations. Determining the application and suitability for use of any product is the responsibility of the installer. Additionally, the installer is responsible for verifying dimensional data on the actual product prior to beginning any installation preparations.

Incentive and rebate programs have precise requirements as to product performance and certification. All products meet applicable regulations in effect on date of manufacture; however, certifications are not necessarily granted for the life of a product. Therefore, it is the responsibility of the applicant to determine whether a specific model qualifies for these incentive/rebate programs.



1900 Wellworth Avenue • Jackson, MI 49203 • 517-787-2100